

Anziehvorschrift Zylinderkopf

Tightening Instructions for Cylinder Head

Instructions de serrage pour culasse

Prescripciones de apriete para culatas

626.727

passend für / suitable for
adaptable à / adaptable a


Fiat/Lancia/Alfa Romeo



Das Original


Schraubenkopf / Head shape
Tête de vis / Cabeza de tornillo

Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete



152.080

M 10x1,25x254



Anziehen/
Tightening/
Serrage/
Apriete

- ⊙ 20 Nm
- ⊙ 40 Nm
- 90°
- 90°
- 90°

Zeichenerklärung / Explanations / Explication / Explicacion

	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
	Setzzeit	relaxation time	durée de tassement	tiempo de espera
	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor

Ø,49 mm ÷

Barchetta, N. Punto, Stilo 1,8 Ltr.

Mot. 188.A6.000, 192.A4.000

Lybra 1,8 Ltr.

Alfa 147, 156, 166 1,6-2,0 Ltr.

Mot. AR 32104, AR 37203, AR 32205, AR 36301

Elring-Serviceteam

Fon +49 7123 724 799

Fax +49 7123 724 798

service@elring.de

26/06/25

626.727